

How to register a PIN for a Private Room



Open the ten-key cover.

Open the cover inside of the door.

Press the black button once.



Check if the pencil icon and the numbers (1·2·3) are displayed on the ten-key panel.

Register a Four-digit PIN number, and then press E.

Close the cover inside of the door.

Once the figures above are displayed, press the number 1.